



**MONITOR AUDIO**

*As close as it gets®*



## CUT-OUT TEMPLATE

Position of clamp fixings x 4

How to use this template

- 1) Remove the Protective backing from the "low tack" adhesive tape on rear of this template.
- 2) Align centre lines (optional)
- 3) The outside profile is an accurate indication of the speaker box hole required.
- 4) Draw around the profile, remove template and cut hole.
- 5) The template can be repositioned a number of times if required.

173mm (6 13/16") DIAMETER

